

## Ordering Information:

Model	Description
4104XT	Explosion Proof Probe Enclosure for Hazardous Area Location
4104WT	NEMA 4 Weather Proof Enclosure for Safe Area Location
4104X	Non-Temperature PIM in Explosion Proof Enclosure
4104W	Non-Temperature PIM in Nema 4 Enclosure

  

Code	Number of Channels of Safety Barriers (See Note 1)
T	0 – Non-installed 1,2,3,4 – Number of channels fitted with safety barriers (for probes in hazardous areas) Supply Voltage (Non-Temperature PIMS only)
115	115 VAC 50/60 Hz
230	230 VAC 50/60 Hz

  

4104XT	—	4	—	115	← Example
--------	---	---	---	-----	-----------

**Note 1:** Space is available for a full set of safety barriers. For economy, only the required number of sets for active probes may be fitted.